TECHNICAL GUIDE



PRO 170, PRO 220 WITH CONVERSION KIT (302707) FOR SEADOO SWITCH®

Congratulations on your new Wave Armor PRO boat port. Our drive on ports accommodate a variety of watercraft. We're going to show you just how easy it is to get the right adjustments and fit your watercraft to perfection. Please follow these next few steps and enjoy.


Tools needed:

- 9/16" Socket and Ratchet
- 9/16" Wrench
- Cordless Impact ¼" Drive
- Cordless Drill
- 9/16" Driver for Cordless Impact
- 1/2" Drill Bit
- Tape Measure
- Pencil/Permanent Marker
- 2' Pry Bar
- 2 LB or Larger Mallet


Step 1. Confirm your application, circle your application below in segments A, B & C.

A. PORT MODEL

PRO 170 Switch® 13'



PRO 220 Switch® 16', 18', 19', 21'



B. SEADOO SWITCH® SIZE

Switch® 13' Switch® 16'

Switch® 18'

Switch® 19'

Switch® 21'












C. MOUNTING CONFIGURATION

OPTION 1 Front Mount:

Pro Port To Wave Dock (302196)




Pro Port To Floating Dock or Wall (302197/302198)




OPTION 2 Side Mount: (*Must Use Pro Inline Side Wing (302498) With Side Slide Assemblies*)

Side Mount Slide Assembly To Wave Dock (302789)




Side Mount Slide Assembly To Floating Dock (302793)




OPTION 3 Post Mount:

Pro Side Post Attachment

- 2" 302649
- 3" 302650






Pro Port Pipe Sleeve

- 2" 302128
- 3" 302152
- 4" 302768



Step 2. Adjust Wheels & Spacers To Fit Your Machine (Recommended Settings)



Step 3. Install Friction Pads Per Application

Friction Pads	Front Mounted	Side Mounted	Post Mounted	Wheel Pocket Location 8 or 9		
PRO 170, 13' Switch	YES	YES	NO	8		
PRO 220 16/18' Switch	NO	NO	NO	9		
PRO 220 19/21' Switch	YES	YES	NO	9		

^{*}Refer to wheel pocket locations shown on step 2

^{*}Use friction pads in place of wheel to prevent roll back when loading onto port





Step 4. Set 4" Aluminum Rails

Front of Aluminum Rail	Front Bolt Location			
PRO 170, 13" Switch	1			
PRO 220 16/18' Switch	3			
PRO 220 19/21' Switch	2			


^{*}Place rails and leave bolts loose until step 5

PRO 170, 13' SWITCH PRO 220, 16/18' SWITCH





PRO 220, 19/21' SWITCH




Step 5. Set Bow Stop


Bow Stop Bolt Location	W/ Power Launch Assist	Stationary		
PRO 170, 13' Switch	19.5	41.5		
PRO 220 16/18' Switch	45.5	67.5		
PRO 220 19/21' Switch	29.5	51.5		

^{*}Remove 4" aluminum rails from port before drilling holes, to prevent damage to port.

W/ POWER LAUNCH ASSIST EXAMPLE



STATIONARY EXAMPLE




Step 6. Install Keel Rest Pad

Keel Rest Pad Needed	YES / NO
PRO 170, 13' Switch	NO
PRO 220 16/18' Switch	YES
PRO 220 19/21' Switch	YES

^{*}Use either forward, center, or rear fastening slots.

^{*}Keep keel rest pad as close to bow stop as possible while also maintaining 25" minimum open space between the nose of bow stop and pad (with bow stop fully retracted).



^{*}Loosely thread all 10 bolts then tighten.

Step 7. Install Buoyancy Boosters (Recommended)

Buoyancy Boosters	Front Mounted		Side Mounted		Post Mounted				
	YES/NO	QTY	LOCATION	YES/NO	QTY	LOCATION	YES/NO	QTY	LOCATION
PRO 170 13" SWITCH	NO	-	-	YES	2	5	NO	-	-
PRO 220 16/18' SWITCH	NO	-	-	YES	2	5	YES	2	2
PRO 220 19/21' SWITCH	YES	2	3	YES	2	2	YES	2	2

