



Attach Two Wave Port Sides Together, Part 21902

Although it is not necessary that two Wave Ports be connected, some people may want to do this.

1. Position two Wave Ports (Part J) side by side in the water.
2. Slide a 16" H-beam (Part V) into the back (entrance side) channels on the undersides of the ports.
3. Slide a 16" C-clamp (Part T) over the H-beam and against the bottom of the port, lining up the holes in the C-clamp with the threaded inserts in the bottom of the port. Alternatively you may be able to loosely attach the C-clamps on land and then slide the H-beam in out on the water. Then tighten the C-clamps with the 3/8 bolts & washers.
4. Attach the C-clamp with 3 bolts and washers.

